



KGS-2421 KGS-1620

Console & Telnet Management Interface

User's Manual



DOC.101115

(C) 2010 KTI Networks Inc. All rights reserved. No part of this documentation may be reproduced in any form or by any means or used to make any derivative work (such as translation or transformation) without permission from KTI Networks Inc.

KTI Networks Inc. reserves the right to revise this documentation and to make changes in content from time to time without obligation on the part of KTI Networks Inc. to provide notification of such revision or change.

For more information, contact:

United States KTI Networks Inc.
P.O. BOX 631008
Houston, Texas 77263-1008

Phone: 713-2663891
Fax: 713-2663893
E-mail: kti@ktinet.com
URL: <http://www.ktinet.com/>

International Fax: 886-2-26983873
E-mail: kti@ktinet.com.tw
URL: <http://www.ktinet.com.tw/>

The information contained in this document is subject to change without prior notice. Copyright (C) All Rights Reserved.

TRADEMARKS

Ethernet is a registered trademark of Xerox Corp.

Vitesse Switch Software. Copyright (c) 2002-2009

Vitesse Semiconductor Corporation "Vitesse". All Rights Reserved.

Unpublished rights reserved under the copyright laws of the United States of America, other countries and international treaties. Permission to use, copy, store and modify, the software and its source code is granted. Permission to integrate into other products, disclose, transmit and distribute the software in an absolute machine readable format (e.g. HEX file) is also granted. The software may only be used in products utilizing the Vitesse switch products.

Table of Contents

1. General	12
1.1 General Commands	12
1.2 Command Groups.....	12
2. System (System settings and reset options)	13
2.1 Configuration	13
2.2 Name.....	13
2.3 Contact.....	14
2.4 Location.....	14
2.5 Timezone	14
2.6 Reboot.....	15
2.7 Restore Default	15
2.8 Password	15
2.9 Load	15
2.10 Log	16
3. IP (IP configuration and Ping)	17
3.1 Configuration	17
3.2 DHCP	17
3.3 Setup.....	17
3.4 Ping	18
3.5 SNTP.....	18
4. Port (Port management)	19
4.1 Configuration	19
4.2 State.....	19
4.3 Mode	20
4.4 FlowControl	20
4.5 MaxFrame	20
4.6 Power	21
4.7 Excessive	21
4.8 Statistics.....	22
4.9 VeriPHY	22
5. MAC (MAC address table)	23

5.1 Configuration	23
5.2 Add	23
5.3 Delete	24
5.4 Lookup	24
5.5 Agetime	24
5.6 Learning	24
5.7 Dump	25
5.8 Statistics	25
5.9 Flush	26
6. VLAN (Virtual LAN)	27
6.1 Configuration	27
6.2 Aware	27
6.3 PVID	28
6.4 FrameType	28
6.5 IngressFilter	28
6.6 Add	29
6.7 Delete	29
6.8 Lookup	29
6.9 Status	30
7. PVLAN (Private VLAN).....	31
7.1 Configuration	31
7.2 Add	31
7.3 Delete	31
7.4 Lookup	32
7.5 Isolate	32
8. Security (Security management).....	33
8.1 Switch (Switch security)	33
8.1.1 Password	33
8.1.2 Auth (Authentication).....	33
8.1.2.1 Configuration	33
8.1.2.2 Method	34
8.1.3 SSH(Secure Shell).....	34
8.1.3.1 Configuration	34
8.1.3.2 Mode [enable disable]	35

8.1.4 HTTPS (Hypertext Transfer Protocol over Secure Socket Layer).....	36
8.1.4.1 Configuration.....	36
8.1.4.2 Mode.....	36
8.1.4.3 Redirect.....	36
8.1.5 SNMP (Simple Network Management Protocol).....	37
8.1.5.1 Configuration.....	38
8.1.5.2 Mode.....	38
8.1.5.3 Version.....	38
8.1.5.4 Read Community.....	39
8.1.5.5 Write Community.....	39
8.1.5.6 Trap Mode.....	39
8.1.5.7 Trap Version.....	40
8.1.5.8 Trap Community.....	40
8.1.5.9 Trap Destination.....	40
8.1.5.10 Trap Authentication Failure.....	41
8.1.5.11 Trap Link-up.....	41
8.1.5.12 Trap Inform Mode.....	41
8.1.5.13 Trap Inform Timeout.....	42
8.1.5.14 Trap Inform Retry Times.....	42
8.1.5.15 Trap Probe Security Engine ID.....	43
8.1.5.16 Trap Security Engine ID.....	43
8.1.5.17 Trap Security Name.....	43
8.1.5.18 Engine ID.....	44
8.1.5.19 Community Add.....	44
8.1.5.20 Community Delete.....	44
8.1.5.21 Community Lookup.....	45
8.1.5.22 User Add.....	45
8.1.5.23 User Delete.....	45
8.1.5.24 User Changekey.....	46
8.1.5.25 User Lookup.....	46
8.1.5.26 Group Add.....	46
8.1.5.27 Group Delete.....	47
8.1.5.28 Group Lookup.....	47
8.1.5.29 View Add.....	47

8.1.5.30 View Delete	48
8.1.5.31 View Lookup.....	48
8.1.5.32 Access Add	48
8.1.5.33 Access Delete	49
8.1.5.34 Access Lookup [<index>].....	49
8.2 Network (Network security)	50
8.2.1 Psec (Port Security Status).....	50
8.2.1.1 Switch.....	50
8.2.1.2 Port.....	50
8.2.2 NAS (Network Access Server - IEEE 802.1X)	51
8.2.2.1 Configuration	51
8.2.2.2 Mode	51
8.2.2.3 State.....	52
8.2.2.4 Reauthentication	52
8.2.2.5 ReauthPeriod	52
8.2.2.6 EapolTimeout.....	53
8.2.2.7 Agetime	53
8.2.2.8 Holdtime	53
8.2.2.9 Authenticate	54
8.2.2.10 Statistics.....	54
8.2.3 ACL (Access Control List).....	55
8.2.3.1 Configuration	55
8.2.3.2 Action	55
8.2.3.3 Policy.....	56
8.2.3.4 Rate.....	56
8.2.3.5 Add.....	56
8.2.3.6 Delete.....	58
8.2.3.7 Lookup	58
8.2.3.8 Clear.....	59
8.2.3.9 Status.....	59
8.3 AAA(Authentication, Authorization and Accounting).....	59
8.3.1 Configuration.....	60
8.3.2 Timeout	60
8.3.3 Deadtime.....	60

8.3.4 RADIUS	60
8.3.5 Statistics	61
9. STP (Spanning Tree Protocol)	62
9.1 Configuration	62
9.2 Version	63
9.3 Txhold	63
9.4 MaxHops	63
9.5 MaxAge	63
9.6 FwdDelay	64
9.7 bpduFilter	64
9.8 bpduGuard	64
9.9 recovery	65
9.10 CName	65
9.11 Status	65
9.12 Msti Priority	66
9.13 Msti Map	66
9.14 Msti Add	66
9.15 Port Configuration	67
9.16 Port Mode	67
9.17 Port Edge	67
9.18 Port AutoEdge	68
9.19 Port P2P	68
9.20 Port RestrictedRole	68
9.21 Port RestrictedTcn	69
9.22 Port bpduGuard	69
9.23 Port Statistics	69
9.24 Port Mcheck	70
9.25 Msti Port Configuration	70
9.26 Msti Port Cost	70
9.27 Msti Port Priority	71
10. IGMP (Internet Group Management Protocol snooping)	72
10.1 Configuration	72
10.2 Mode	72
10.3 State	73

